



EUROTECH INDOOR & OUTDOOR WALL SOUNDER

The 100-3801V Wall Mounted Sounder forms the core of our Alarm Device Range.

The unit is of modular design and is also available: 100-2114V Addressable Wall Sounder compromising of 100-3801V (EURVC-S Wall Mounted Sounder) plus 100-2050V (EURV-MOD Addressable Module c/w Isolator).

The unit is also available in white as 100-2114VW, compromising of 100-3801VW (EURVC-S Wall Mounted Sounder) plus 100-2050V (EURV-MOD Addressable Module c/w Isolator).

The unit has a built-in microphone which allows the unit to indicate a fault should the sounder not operate when activated or tested.

TECHNICAL INFORMATION

- **KEY FEATURES**
- Third party approved to the requirements of EN54-3
- 32 Tone Settings
- Two stage alarm capability
- Easy to install
- High sound output capability
- On site adjustable volume settings
- Microphone self test facility
- Robust & high reliability
- IP65 Rated as standard

TECHNICAL SPECIFICATION

- Power supply voltage range
- Activated Current Load (High Vol.)
- Acoustic Frequency Range
- Maximum acoustic Output
- Operating Temperature Range
- Unit Weight (incl. back box)
- Max tolerated humidity
- IP Rating

18Vdc - 40Vdc 11-25 mA at 24Vdc 400-2900 Hz 100 dB[A] @ 1m -25 C to +70 C 290 g 95% RH [non-condensing] IP65

STANDARDS & APPROVALS

• EN54-3:2014 Fire Alarm Device, Sounders



T: 0203 141 0999


F: 0239 225 2554



OUTPUT VOLUME SETTING

Use the DIP switch at the back of the sounder body for setting the output volume; in particular, switches 6 and 7 are used. The switches positioned upwards acquire value '1' or when positioned downwards acquire value '0'.

Refer to the table below and set the position of both switches 6 and 7 according to the required volume when the sounder is active.



| Tone volume | Switch 6 | Switch 7 | dB(A) evaluation | Notes |
|-------------|----------|----------|------------------|-----------|
| HIGH | 1 | 1 | 100 dB(A) +0/-3 | All tones |
| MEDIUM HIGH | 0 | 1 | | All tones |
| MEDIUM LOW | 1 | 0 | | All tones |
| LOW | 0 | 0 | | |


OUTPUT TONE SETTING

Use the DIP switch at the back of the sounder body for setting the output tone; in particular, switches 1 to 5 are used. The switches positioned upwards acquire value '1' or when positioned downwards acquire value '0'.

Using the DIP switches it is possible to select a tone between 1 and 32. Utilises the Standard or Alternative wiring connections determines whether this tone is selected from the Standard of Alternative tone tables [Page 4 and 5], when the sounder is activated.

When using the Intelligent interface module the Standard and alternative tones may be selected via the loop protocol and control panel settings.*

*Note: Not all functionality may be available on all control equipment. Contact the technical support for specific advice.



T: 0203 141 0999

0239 225 2554



STANDARD TONE TABLE

| No: | Tone Description | Tone Description | 1 | 2 | 3 | 4 | 5 |
|-----|-----------------------------------|---|---|---|---|---|---|
| 1 | Warble Tone | 800Hz for 500ms, then 1000Hz for 500ms | 1 | 1 | 1 | 0 | 1 |
| 2 | Continous Tone | 970Hz continuous tone | 0 | 1 | 0 | 1 | 1 |
| 3 | Slow Whoop (Dutch) | 500-1200Hz for 3500ms, then off for 500ms | 1 | 0 | 1 | 0 | 1 |
| 4 | German DIN Tone | 1200Hz-500Hz sweep every 1000ms (1Hz) | 0 | 0 | 1 | 1 | 1 |
| 5 | Alternative HF slow sweep | 2350Hz-2900Hz sweep every 333ms (3Hz) | 1 | 0 | 0 | 1 | 0 |
| 6 | Alternative Warble | 800Hz for 250ms, then 960Hz for 250ms | 1 | 1 | 1 | 1 | 0 |
| 7 | Alternative Warble | 500Hz for 250ms, then 600Hz for 250ms | 1 | 1 | 1 | 1 | 0 |
| 8 | Analogue Sweep Tone | 500Hz-600Hz sweep every 500ms (2Hz) | 1 | 0 | 1 | 0 | 0 |
| 9 | Australian Alert (intermittent) | 970Hz for 625ms, then off for 625ms | 1 | 0 | 0 | 0 | 1 |
| 10 | Australian Evac (slow whoop) | 500-1200Hz sweep for 3750ms, then OFF for 250ms | 1 | 0 | 1 | 1 | 0 |
| 11 | FP1063.1- Telecom | 800Hz for 250ms, then 970Hz for 250ms | 0 | 0 | 0 | 0 | 1 |
| 12 | French Tone (Afnor) | 554Hz for 100ms then 440Hz for 400ms | 0 | 0 | 0 | 0 | 1 |
| 13 | HF Back Up interupted Tone | 2800Hz for 1sec then off for 1 second | 1 | 1 | 0 | 1 | 1 |
| 14 | HF Back Up interupted Tone (fast) | 2800Hz for 150ms, then off for 150ms | 1 | 1 | 0 | 0 | 1 |
| 15 | HF Continous | 2800Hz continuous | 0 | 1 | 0 | 0 | 1 |
| 16 | Interrupted Tone | 800Hz for 500ms, then off for 500ms | 0 | 1 | 1 | 1 | 1 |
| 17 | Interrupted Tone medium | 1000Hz for 250ms, then off for 250ms | 0 | 1 | 1 | 0 | 1 |
| 18 | ISO 8201 LF BS5839 Pt1 1988 | 970Hz for 500ms, then OFF for 500ms | 0 | 1 | 1 | 1 | 0 |
| 19 | ISO 8201 HF | 2800Hz for 500ms, then OFF for 500ms | 0 | 1 | 1 | 0 | 0 |
| 20 | LF Backup Alarm | 800Hz for 150ms, then OFF for 150ms | 1 | 1 | 0 | 1 | 0 |
| 21 | LF Buzz | 800Hz-950Hz sweep every 9ms | 0 | 1 | 0 | 1 | 0 |
| 22 | LF Continous Tone BS5839 | 800Hz continuous | 1 | 1 | 0 | 0 | 0 |
| 23 | Silent | No Sound | 1 | 1 | 1 | 1 | 1 |
| 24 | Siren 2 way ramp (long) | 500-1200Hz rising for 3000ms, then falling for 3000ms | 0 | 0 | 0 | 0 | 0 |
| 25 | Siren 2 way ramp (short) | 500-1200Hz rising for 250ms, then falling for 250ms | 0 | 0 | 0 | 1 | 0 |
| 26 | Swedish All Clear | 660Hz continuous | 0 | 0 | 1 | 0 | 0 |
| 27 | Swedish Fire Signal | 660Hz for 150ms, then OFF for 150ms | 0 | 0 | 1 | 1 | 0 |
| 28 | Sweep Tone (1Hz) | 800-900Hz sweep every 1000ms | 1 | 0 | 1 | 1 | 1 |
| 29 | Sweep Tone (3Hz) | 800-970Hz sweep every 333ms | 1 | 0 | 0 | 1 | 1 |
| 30 | Sweep Tone (9Hz) | 800-970Hz sweep every 111ms | 0 | 1 | 0 | 0 | 0 |
| 31 | US Temporal Pattern HF | (2900Hz for 500ms,then 500ms off) x3 then 1500ms off | 0 | 0 | 0 | 1 | 1 |
| 32 | LF Sweep (Cranford Tone) | 800Hz -1000Hzsweep every 500ms (2Hz) | 1 | 0 | 0 | 0 | 0 |

W: www.eurotechfire.com

T: 0203 141 0999

: 0239 225 2554



ALTERNATIVE TONE TABLE

| No: | Tone Description | 1 | 2 | 3 | 4 | 5 |
|-----|---|---|---|---|---|---|
| 1 | 800Hz continuous | 1 | 1 | 1 | 0 | 1 |
| 2 | 1000Hz continuous tone | 0 | 1 | 0 | 1 | 1 |
| 3 | 500-1200Hz for 3500ms, then off for 500ms | 1 | 0 | 1 | 0 | 1 |
| 4 | 800Hz continuous | 0 | 0 | 1 | 1 | 1 |
| 5 | 2400Hz continuous | 1 | 0 | 0 | 1 | 0 |
| 6 | 800Hz continuous | 1 | 1 | 1 | 1 | 0 |
| 7 | 500Hz continuous | 1 | 1 | 1 | 1 | 0 |
| 8 | 500Hz continuous | 1 | 0 | 1 | 0 | 0 |
| 9 | 2400Hz continuous | 1 | 0 | 0 | 0 | 1 |
| 10 | 500-1200Hz sweep for 3750ms, then OFF for 250ms | 1 | 0 | 1 | 1 | 0 |
| 11 | 500-1200Hz rising for 250ms, then falling for 250ms | 0 | 0 | 0 | 0 | 1 |
| 12 | 800Hz continuous | 0 | 0 | 0 | 0 | 1 |
| 13 | 2800Hz continuous | 1 | 1 | 0 | 1 | 1 |
| 14 | 800Hz continuous | 1 | 1 | 0 | 0 | 1 |
| 15 | 2800Hz continuous | 0 | 1 | 0 | 0 | 1 |
| 16 | 800Hz continuous | 0 | 1 | 1 | 1 | 1 |
| 17 | 800Hz continuous | 0 | 1 | 1 | 0 | 1 |
| 18 | 970Hz for 500ms, then OFF for 500ms | 0 | 1 | 1 | 1 | 0 |
| 19 | 2850Hz for 500ms, then OFF for 500ms | 0 | 1 | 1 | 0 | 0 |
| 20 | 800Hz continuous | 1 | 1 | 0 | 1 | 0 |
| 21 | 800Hz continuous | 0 | 1 | 0 | 1 | 0 |
| 22 | 800Hz continuous | 1 | 1 | 0 | 0 | 0 |
| 23 | 800Hz continuous | 1 | 1 | 1 | 1 | 1 |
| 24 | 800Hz continuous | 0 | 0 | 0 | 0 | 0 |
| 25 | 800Hz continuous | 0 | 0 | 0 | 1 | 0 |
| 26 | 660Hz continuous | 0 | 0 | 1 | 0 | 0 |
| 27 | 660Hz for 150ms, then OFF for 150ms | 0 | 0 | 1 | 1 | 0 |
| 28 | 800Hz continuous | 1 | 0 | 1 | 1 | 1 |
| 29 | 800Hz continuous | 1 | 0 | 0 | 1 | 1 |
| 30 | 800Hz continuous | 0 | 1 | 0 | 0 | 0 |
| 31 | 2900Hz continuous | 0 | 0 | 0 | 1 | 1 |
| 32 | 800Hz continuous | 1 | 0 | 0 | 0 | 0 |

0203 141 0999

0239 225 2554